

CHIP DRUM HP CE314A | HP1025 (14K) PROFIT  
CHIP DRUM HP CE314A | HP1025 (14K) PROFIT IMP  
CHIP DRUM HP CF219A | M132 (12K) PROFIT  
CHIP DRUM LEXMARK MS | MX 310 | 410 | 510 | 610 (60K) PROFIT  
CHIP DRUM LEXMARK MS | MX 310 | 410 | 510 | 610 (60K) PROFIT IMP  
CHIP DRUM LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (100K) PROFIT  
CHIP DRUM LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (100K) PROFIT IMP  
CHIP DRUM MINOLTA 3730 (5K) AMAR PROFIT  
CHIP DRUM MINOLTA 3730 (5K) AZUL PROFIT  
CHIP DRUM MINOLTA 3730 (5K) PRET PROFIT  
CHIP DRUM MINOLTA 3730 (5K) VERM PROFIT  
CHIP DRUM MINOLTA 4650 | 4690 | 4695 (18K) AMAR PROFIT  
CHIP DRUM MINOLTA 4650 | 4690 | 4695 (18K) AZUL PROFIT  
CHIP DRUM MINOLTA 4650 | 4690 | 4695 (18K) VERM PROFIT  
CHIP DRUM MINOLTA 4650 | 4690 | 4695 (30K) PRET PROFIT  
CHIP DRUM MINOLTA 4750 | 4790 | 4795 (30K) AMAR PROFIT  
CHIP DRUM MINOLTA 4750 | 4790 | 4795 (30K) AZUL PROFIT  
CHIP DRUM MINOLTA 4750 | 4790 | 4795 (30K) PRET PROFIT  
CHIP DRUM MINOLTA 4750 | 4790 | 4795 (30K) VERM PROFIT  
CHIP DRUM MINOLTA 7450 (12K) AMAR PROFIT  
CHIP DRUM MINOLTA 7450 (12K) AZUL PROFIT  
CHIP DRUM MINOLTA 7450 (12K) VERM PROFIT  
CHIP DRUM MINOLTA 7450 (15K) PRET PROFIT  
CHIP DRUM MINOLTA 8650 (120K) PRET PROFIT  
CHIP DRUM MINOLTA 8650 (90K) AMAR PROFIT  
CHIP DRUM MINOLTA 8650 (90K) AZUL PROFIT  
CHIP DRUM MINOLTA 8650 (90K) VERM PROFIT  
CHIP DRUM MINOLTA BIZHUB C250 | C252 (12K) AMAR PROFIT  
CHIP DRUM MINOLTA BIZHUB C250 | C252 (12K) AZUL PROFIT  
CHIP DRUM MINOLTA BIZHUB C250 | C252 (12K) VERM PROFIT  
CHIP DRUM MINOLTA BIZHUB C250 | C252 (20K) PRET PROFIT  
CHIP DRUM MINOLTA BIZHUB C35 (30K) AMAR PROFIT  
CHIP DRUM MINOLTA BIZHUB C35 (30K) AZUL PROFIT  
CHIP DRUM MINOLTA BIZHUB C35 (30K) PRET PROFIT  
CHIP DRUM MINOLTA BIZHUB C35 (30K) VERM PROFIT  
CHIP DRUM OKIDATA MB410 | MB420 | MB430 | MB440 (25K) PROFIT  
CHIP DRUM RICOH MP401 | 4520DN (20K) PROFIT  
CHIP DRUM RICOH SP3600 | SP3610 | SP4510 (20K) PROFIT  
CHIP DRUM RICOH SP3600 | SP3610 | SP4510 (20K) PROFIT IMP  
CHIP DRUM RICOH SP4500 | SP4510 (19K) PROFIT  
CHIP DRUM SAMSUNG MLT-R116L | M2825 | M2835 | M2875 | M2885 (3K) PROFIT  
CHIP DRUM SAMSUNG MLT-R204 | M3325 | M3375 | M3825 | M3875 (30K) PROFIT

CHIP DRUM SAMSUNG MLT-R204 | M3325 | M3375 | M3825 | M3875 (30K) PROFIT IMP  
CHIP DRUM SAMSUNG MLT-R303E | M4580 (100K) PROFIT  
CHIP DRUM SAMSUNG MLT-R303E | M4580 (100K) PROFIT IMP  
CHIP DRUM SAMSUNG MLT-R307 | ML4510 | ML5010 | ML5015 (60K) PROFIT  
CHIP DRUM SAMSUNG SCX-R6555A | SCX6545 (80K) PROFIT  
CHIP DRUM SAMSUNG SCX-R6555A | SCX6545 (80K) PROFIT IMP  
CHIP DRUM XEROX B600 | B605 | B610 | B615 (60K) PROFIT  
CHIP DRUM XEROX B600 | B605 | B610 | B615 (60K) PROFIT IMP  
CHIP DRUM XEROX PHASER 3215 | 3225 | 3052 | 3260 (3K) PROFIT  
CHIP DRUM XEROX PHASER 5016 | 5020 (22K) PROFIT  
CHIP HP CB435A | CB436A | CE285A | CE278A | CF283A | CE505A TRKM18 IMP  
CHIP HP CB435A | CB436A | CF280X | CE255X | CE364X | CE278A | CF283A | CF325X TRKM8 IMP  
CHIP HP CB436A | CE278A | CE283A | CE505X | CE390X | CE255X TRKM6 IMP  
CHIP HP CE310A | CF350A | CE400A | CC530A | CF210A | CE740A TRKC6 PRET PROFIT  
CHIP HP CE311A | CE401A | CC531A | CF211A | CE741A | CE261A TIMPC6 AZUL PROFIT  
CHIP HP CE312A | CE402A | CC532A | CF212A | CE742A | CE262A TRYC6 AMAR PROFIT  
CHIP HP CE313A | CE403A | CC533A | CF213A | CE263A | CE743A TRMC6 VERM PROFIT  
CHIP HP CF280A | PRO400 | M401 | 425 (2,7K) IMP  
CHIP HP CF280X | PRO400 | M401 | 425 (6,9K) IMP  
CHIP HP CF350A | M176N | M177FW PRET (1,3K) IMP  
CHIP HP CF351A | M176N | M177FW AZUL (1K) IMP  
CHIP HP CF352A | M176N | M177FW AMAR (1K) IMP  
CHIP HP CF353A | M176N | M177FW VERM (1K) IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) AMAR PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) AMAR PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) AZUL PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) AZUL PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) PRET PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) PRET PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) VERM PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5210 | 5710 | 5290 | 5790 (5K) VERM PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5290 | 5790 (10K) PRET PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5290 | 5790 (10K) PRET PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5299 | 5799 (40K) PRET PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5299 | 5799 (40K) PRET PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) AMAR PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) AMAR PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) AZUL PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) AZUL PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) PRET PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) PRET PROFIT IMP  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) VERM PROFIT  
CHIP JATO DE TINTA EPSON WORKFORCE 5690 | 7861 | 4640 | 5110 | 5190 | 5620 (4K) VERM PROFIT IMP

CHIP JATO DE TINTA HP 950XL (2,3K) PRET PROFIT IMP  
CHIP JATO DE TINTA HP 951XL (1,5K) AMAR PROFIT  
CHIP JATO DE TINTA HP 951XL (1,5K) AMAR PROFIT IMP  
CHIP JATO DE TINTA HP 951XL (1,5K) AZUL PROFIT  
CHIP JATO DE TINTA HP 951XL (1,5K) AZUL PROFIT IMP  
CHIP JATO DE TINTA HP 951XL (1,5K) VERM PROFIT  
CHIP JATO DE TINTA HP 951XL (1,5K) VERM PROFIT IMP  
CHIP JATO DE TINTA HP 974XL (10K) PRET PROFIT IMP  
CHIP JATO DE TINTA HP 974XL (7K) AMAR PROFIT IMP  
CHIP JATO DE TINTA HP 974XL (7K) AZUL PROFIT IMP  
CHIP JATO DE TINTA HP 974XL (7K) VERM PROFIT IMP  
CHIP JATO DE TINTA HP 974XL | ARC | AUTO RESET CHIP | FULL AMAR PROFIT IMP  
CHIP JATO DE TINTA HP 974XL | ARC | AUTO RESET CHIP | FULL AZUL PROFIT IMP  
CHIP JATO DE TINTA HP 974XL | ARC | AUTO RESET CHIP | FULL PRET PROFIT IMP  
CHIP JATO DE TINTA HP 974XL | ARC | AUTO RESET CHIP | FULL VERM PROFIT IMP  
CHIP JATO DE TINTA HP950XL (2,3K) PRET PROFIT  
CHIP LEXMARK AJL-200BKXL | PRO4000 | 5500 | 5500T PRET IMP  
CHIP LEXMARK AJL-200CXL | PRO4000 | 5500 | 5500T AZUL IMP  
CHIP LEXMARK AJL-200MXL | PRO4000 | 5500 | 5500T VERM IMP  
CHIP LEXMARK AJL-200YXL | PRO4000 | 5500 | 5500T AMAR IMP  
CHIP LEXMARK MS410 | MS610 | 504 (10K) IMP  
CHIP LEXMARK MX 710 | MX711 | MX810 | MX811 | MX812 ( 25K ) IMP  
CHIP LEXMARK MX511 | MX510 | MX610 | MX611 | 600F4X00 (20K) IMP  
CHIP MANUTENÇÃO DA LIXEIRA EPSON WORKFORCE 2860 | 2865 ECOTANK 1140 | 1170 | 1180 | 2140 | 3140 IMP  
CHIP MANUTENÇÃO DA LIXEIRA EPSON WORKFORCE 5710 | 5790 | 5799 | 5210 | 5290 | 5298 | 5299  
CHIP MANUTENÇÃO DA LIXEIRA EPSON WORKFORCE 5710 | 5790 | 5799 | 5210 | 5290 | 5298 | 5299 IMP  
CHIP TONER HP278 | CE278A | 1606 (2K) PROFIT  
CHIP TONER KYOCERA TK3122 | FS4200DN (21K) PROFIT  
CHIP TONER KYOCERA TK3122 | FS4200DN (21K) PROFIT IMP  
CHIP TONER SAMSUNG ML3560 | ML3561 (12K) PROFIT  
CHIP TONER CANON CRG041H | LBP312 (20K) PROFIT  
CHIP TONER HP 1600 | 2600 | 2605 | 2700 (2K) PRET PROFIT  
CHIP TONER HP 2025 | CM2320 | CP2020 | CM720 | CB530A (3,5K) PRET PROFIT  
CHIP TONER HP 2025 | CM2320 | CP2020 | CM720 | CB532A (2,8K) AMAR PROFIT  
CHIP TONER HP 2025 | CM2320 | CP2020 | CM720 | CB533A (2,8K) VERM PROFIT  
CHIP TONER HP C8543X | 9000 | 9050 | 9040 (30K) PROFIT  
CHIP TONER HP C8543X | 9000 | 9050 | 9040 (30K) PROFIT IMP  
CHIP TONER HP C9730A | 5500 (13K) PRET PROFIT  
CHIP TONER HP C9731A | 5500 (12K) AZUL PROFIT  
CHIP TONER HP C9732A | 5500 (12K) AMAR PROFIT  
CHIP TONER HP C9733A | 5500 (12K) VERM PROFIT  
CHIP TONER HP CB435A | CB436A | CE278A | CE285A | CE505X | CE280X | CE255X | CC364X TRKM2 PROFIT

CHIP TONER HP CB435A | CB436A | CE278A | CE285A | CE505X | CE280X | CE255X | CC364X TRKM2 PROFIT IMP  
CHIP TONER HP CB435A | CB436A | CE278A | CF283A | CE505A | CE255A TRKM5 PROFIT  
CHIP TONER HP CB435A | CB436A | CE278A | CF283A | CE505A | CE255A TRKM5 PROFIT IMP  
CHIP TONER HP CB435A | CB436A | CE505A | CE255A | CE364A | CE278A | CE285A | CE280A TRKM1 PROFIT  
CHIP TONER HP CB435A | CB436A | CE505A | CE255A | CE364A | CE278A | CE285A | CE280A TRKM1 PROFIT IMP  
CHIP TONER HP CB436A | CE505A | CE255A | CE364A | CE278A | CE285A | CE280A | CF283A TRKM30 PROFIT IMP  
CHIP TONER HP CB531A | 2025 | CM2320 | CP2020 | CM720 (2,8K) AZUL PROFIT  
CHIP TONER HP CB540A | CC530A | CE400A | CE310A | CE260A | CE410A | CF380A | CE250A TRKC31 PRET IMP  
CHIP TONER HP CB541A | CC531A | CE401A | CE311A | CE261A | CE411A | CF381A | CE251A TRCC31 AZUL IMP  
CHIP TONER HP CB542A | CC532A | CE402A | CE312A | CE262A | CE412A | CF382A | CE252A TRYC31 AMAR IMP  
CHIP TONER HP CB543A | CC533A | CE403A | CE313A | CE263A | CE413A | CF383A | CE253A TRMC31 VERM IMP  
CHIP TONER HP CC364A | 4014 | 4015 | 4515 (10K) PROFIT  
CHIP TONER HP CC364X | 4015 | 4515 (24K) PROFIT  
CHIP TONER HP CE250A | CP3525 | CM3530 (5K) PRET PROFIT  
CHIP TONER HP CE251A | CP3525 | CM3530 (7K) AZUL PROFIT  
CHIP TONER HP CE252A | CP3525 | CM3530 (7K) AMAR PROFIT  
CHIP TONER HP CE253A | CP3525 | CM3530 (7K) VERM PROFIT  
CHIP TONER HP CE310 | CE320 | CB530 | CB540 | CE410 | 1025 | 1525 | 1215 | U10 PRET PROFIT  
CHIP TONER HP CE310A | 1025 (1,2K) PRET PROFIT  
CHIP TONER HP CE311 | CE321 | CB531 | CB541 | CE411 | 1025 | 1525 | 1215 | U10 AZUL PROFIT  
CHIP TONER HP CE311A | 1025 (1K) AZUL PROFIT  
CHIP TONER HP CE312 | CE322 | CB532 | CB542 | CE412 | 1025 | 1525 | 1215 | U10 AMAR PROFIT  
CHIP TONER HP CE312A | 1025 (1K) AMAR PROFIT  
CHIP TONER HP CE313 | CE323 | CB533 | CB543 | CE413 | 1025 | 1525 | 1215 | U10 VERM PROFIT  
CHIP TONER HP CE313A | 1025 (1K) VERM PROFIT  
CHIP TONER HP CE320A | CC530A | CE310A | CE250A | CE260A | TRKC5 PRET PROFIT  
CHIP TONER HP CE321A | CC531A | CE311A | CE251A | CE261A | TRCC5 AZUL PROFIT  
CHIP TONER HP CE321A | CC531A | CE311A | CE251A | CE261A | TRCC5 AZUL PROFIT  
CHIP TONER HP CE322A | CC532A | CE312A | CE252A | CE262A | TRYC5 AMAR PROFIT  
CHIP TONER HP CE322A | CC532A | CE312A | CE252A | CE262A | TRYC5 AMAR PROFIT  
CHIP TONER HP CE323A | CC533A | CE313A | CE253A | CE 263A | TRMC5 VERM PROFIT  
CHIP TONER HP CE323A | CC533A | CE313A | CE253A | CE 263A | TRMC5 VERM PROFIT  
CHIP TONER HP CE390A | 4550 (10K) PROFIT  
CHIP TONER HP CE390A | 4550 (10K) PROFIT IMP  
CHIP TONER HP CE390X | 4550 (24K) PROFIT  
CHIP TONER HP CE390X | 4550 (24K) PROFIT IMP  
CHIP TONER HP CE400A | 507A | M551 (5,5K) PRET PROFIT  
CHIP TONER HP CE401A | 507A | M551 (6K) AZUL PROFIT  
CHIP TONER HP CE402A | 507A | M551 (6K) AMAR PROFIT  
CHIP TONER HP CE403A | 507A | M551 (6K) VERM PROFIT  
CHIP TONER HP CF210A | PRO200 | M251 (2,2K) PRET PROFIT  
CHIP TONER HP CF211A | PRO200 | M251 (1,4K) AZUL PROFIT

CHIP TONER HP CF212A | PRO200 | M251 (1,4K) AMAR PROFIT  
CHIP TONER HP CF213A | PRO200 | M251 (1,4K) VERM PROFIT  
CHIP TONER HP CF217A (1,6K) PROFIT  
CHIP TONER HP CF218A (1,4K) PROFIT  
CHIP TONER HP CF218A (1,4K) PROFIT IMP  
CHIP TONER HP CF226A | M426DW | M402N (3,1K) PROFIT  
CHIP TONER HP CF226A | M426DW | M402N (3,1K) PROFIT IMP  
CHIP TONER HP CF226X | M426DW | M402N (9K) PROFIT  
CHIP TONER HP CF226X | M426DW | M402N (9K) PROFIT IMP  
CHIP TONER HP CF230A (1,4K) PROFIT  
CHIP TONER HP CF230X | M203DW | MFPM227FDW | 227SDN (3,5K) PROFIT  
CHIP TONER HP CF230X | M203DW | MFPM227FDW | 227SDN (3,5K) PROFIT IMP  
CHIP TONER HP CF248A | M15 | M28 (1K) PROFIT  
CHIP TONER HP CF279A | M12W | M26NW (1K) PROFIT  
CHIP TONER HP CF280X | PRO400 | M401 | 425 (6,9K) PROFIT  
CHIP TONER HP CF281A | M630 (10,5K) PROFIT  
CHIP TONER HP CF281A | M630 (10,5K) PROFIT IMP  
CHIP TONER HP CF281X | M630 (25K) PROFIT IMP  
CHIP TONER HP CF283A | M125 | M127FN (1,5K) PROFIT  
CHIP TONER HP CF283X | PRO M225 | M201 (2,2K) PROFIT IMP  
CHIP TONER HP CF380A | M476NW (2,4K) PRET PROFIT  
CHIP TONER HP CF380A | M476NW (2,4K) PRET PROFIT IMP  
CHIP TONER HP CF380X | M476NW (4,4K) PRET PROFIT  
CHIP TONER HP CF380X | M476NW (4,4K) PRET PROFIT IMP  
CHIP TONER HP CF381A | M476NW (2,4K) AZUL PROFIT  
CHIP TONER HP CF381A | M476NW (2,4K) AZUL PROFIT IMP  
CHIP TONER HP CF382A | M476NW (2,4K) AMAR PROFIT  
CHIP TONER HP CF382A | M476NW (2,4K) AMAR PROFIT IMP  
CHIP TONER HP CF383A | M476NW (2,4K) VERM PROFIT IMP  
CHIP TONER HP CF400A | M252DN (1,5K) PRET PROFIT  
CHIP TONER HP CF400A | M252DN (1,5K) PRET PROFIT IMP  
CHIP TONER HP CF400X | M252DN | 277DW | 274N (2,8K) PRET PROFIT  
CHIP TONER HP CF400X | M252DN | 277DW | 274N (2,8K) PRET PROFIT IMP  
CHIP TONER HP CF401A | M252DN (1,4K) AZUL PROFIT  
CHIP TONER HP CF401A | M252DN (1,4K) AZUL PROFIT IMP  
CHIP TONER HP CF401X | M252DN | 277DW | 274N (2,3K) AZUL PROFIT  
CHIP TONER HP CF401X | M252DN | 277DW | 274N (2,3K) AZUL PROFIT IMP  
CHIP TONER HP CF402A | M252DN (1,4K) AMAR PROFIT  
CHIP TONER HP CF402A | M252DN (1,4K) AMAR PROFIT IMP  
CHIP TONER HP CF402X | M252DN | 277DW | 274N (2,3K) AMAR PROFIT  
CHIP TONER HP CF402X | M252DN | 277DW | 274N (2,3K) AMAR PROFIT IMP  
CHIP TONER HP CF403A | M252DN (1,4K) VERM PROFIT  
CHIP TONER HP CF403A | M252DN (1,4K) VERM PROFIT IMP

CHIP TONER HP CF403X | M252DN | 277DW | 274N (2,3K) VERM PROFIT  
CHIP TONER HP CF403X | M252DN | 277DW | 274N (2,3K) VERM PROFIT IMP  
CHIP TONER HP CF410A | 452NW | 452DN | M452DW (2,3K) PRET PROFIT  
CHIP TONER HP CF410A | 452NW | 452DN | M452DW (2,3K) PRET PROFIT IMP  
CHIP TONER HP CF410X | M452DW | 477FNW (6,5K) PRET PROFIT  
CHIP TONER HP CF410X | M452DW | 477FNW (6,5K) PRET PROFIT IMP  
CHIP TONER HP CF411A | 452NW | 452DN | M452DW (2,3K) AZUL PROFIT  
CHIP TONER HP CF411A | 452NW | 452DN | M452DW (2,3K) AZUL PROFIT IMP  
CHIP TONER HP CF411X | M452DW | 477FNW (5K) AZUL PROFIT  
CHIP TONER HP CF411X | M452DW | 477FNW (5K) AZUL PROFIT IMP  
CHIP TONER HP CF412A | 452NW | 452DN | M452DW (2,3K) AMAR PROFIT  
CHIP TONER HP CF412A | 452NW | 452DN | M452DW (2,3K) AMAR PROFIT IMP  
CHIP TONER HP CF412X | M452DW | 477FNW (5K) AMAR PROFIT  
CHIP TONER HP CF412X | M452DW | 477FNW (5K) AMAR PROFIT IMP  
CHIP TONER HP CF413A | 452NW | 452DN | M452DW (2,3K) VERM PROFIT  
CHIP TONER HP CF413A | 452NW | 452DN | M452DW (2,3K) VERM PROFIT IMP  
CHIP TONER HP CF413X | M452DW | 477FNW (5K) VERM PROFIT  
CHIP TONER HP CF413X | M452DW | 477FNW (5K) VERM PROFIT IMP  
CHIP TONER HP Q2613A | Q5949A | Q7553A | Q2610A | Q6511A | Q7551A | Q1338A | Q5942A PROFIT  
CHIP TONER HP Q2613A | Q5949A | Q7553A | Q2610A | Q6511A | Q7551A | Q1338A | Q5942A PROFIT IMP  
CHIP TONER HP Q2613X | Q5949X | Q6511X | Q7553X | Q7551X | Q1338A | Q5942X | Q1339 PROFIT  
CHIP TONER HP Q2613X | Q5949X | Q6511X | Q7553X | Q7551X | Q1338A | Q5942X | Q1339 PROFIT IMP  
CHIP TONER HP Q6000A | 2600 | 2605 | CM1015 | CM1017 (2,5K) PRET PROFIT  
CHIP TONER HP Q6000A | 2600 | 2605 | CM1015 | CM1017 (2,5K) PRET PROFIT IMP  
CHIP TONER HP Q6001A | 2600 | 2605 | CM1015 | CM1017 (2K) AZUL PROFIT  
CHIP TONER HP Q6001A | 2600 | 2605 | CM1015 | CM1017 (2K) AZUL PROFIT IMP  
CHIP TONER HP Q6002A | 2600 | 2605 | CM1015 | CM1017 (2K) AMAR PROFIT  
CHIP TONER HP Q6002A | 2600 | 2605 | CM1015 | CM1017 (2K) AMAR PROFIT IMP  
CHIP TONER HP Q6003A | 2600 | 2605 | CM1015 | CM1017 (2K) VERM PROFIT  
CHIP TONER HP Q6003A | 2600 | 2605 | CM1015 | CM1017 (2K) VERM PROFIT IMP  
CHIP TONER HP Q7516A | Q7570A | 5200 | M5025 | M5035 | (12K) PROFIT  
CHIP TONER HP W1105A (1K) PROFIT  
CHIP TONER HP W1105A (1K) PROFIT IMP  
CHIP TONER KYOCERA TK1147 | FS1035MFP | 1135MFP (12K) PROFIT  
CHIP TONER KYOCERA TK1147 | FS1035MFP | 1135MFP (12K) PROFIT IMP  
CHIP TONER KYOCERA TK1175 | M2040 | M2640 (12K) PROFIT  
CHIP TONER KYOCERA TK1175 | M2040 | M2640 (12K) PROFIT IMP  
CHIP TONER KYOCERA TK137 | 2810 | 2820 (7,2K) PROFIT  
CHIP TONER KYOCERA TK137 | 2810 | 2820 (7,2K) PROFIT IMP  
CHIP TONER KYOCERA TK3102 | FS2100 | 2100D | M3040 | M3540 (12,5K) PROFIT  
CHIP TONER KYOCERA TK3102 | FS2100 | 2100D | M3040 | M3540 (12,5K) PROFIT IMP  
CHIP TONER KYOCERA TK3105 (12,5K) PROFIT

CHIP TONER KYOCERA TK3132 | FS-4300DN (25K) PROFIT  
CHIP TONER KYOCERA TK3132 | FS-4300DN (25K) PROFIT IMP  
CHIP TONER KYOCERA TK3162 | P3045 | P3050 | P3055 (12,5K) PROFIT  
CHIP TONER KYOCERA TK3162 | P3045 | P3050 | P3055 (12,5K) PROFIT IMP  
CHIP TONER KYOCERA TK3182 | P3055DN (21K) PROFIT  
CHIP TONER KYOCERA TK3182 | P3055DN (21K) PROFIT IMP  
CHIP TONER KYOCERA TK362 | FS4020 (20K) PROFIT  
CHIP TONER KYOCERA TK362 | FS4020 (20K) PROFIT IMP  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) AMAR PROFIT  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) AMAR PROFIT IMP  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) AZUL PROFIT  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) AZUL PROFIT IMP  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) VERM PROFIT  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,2K) VERM PROFIT IMP  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,6K) PRET PROFIT  
CHIP TONER KYOCERA TK5232 | M5521 | P5021 (2,6K) PRET PROFIT IMP  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) AMAR PROFIT  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) AMAR PROFIT IMP  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) AZUL PROFIT  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) AZUL PROFIT IMP  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) VERM PROFIT  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (10K) VERM PROFIT IMP  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (12K) PRET PROFIT  
CHIP TONER KYOCERA TK562 | 5300 | 5350 (12K) PRET PROFIT IMP  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) AMAR PROFIT  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) AMAR PROFIT IMP  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) AZUL PROFIT  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) AZUL PROFIT IMP  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) VERM PROFIT  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (15K) VERM PROFIT IMP  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (25K) PRET PROFIT  
CHIP TONER KYOCERA TK8307 | 3050CI | 3051CI (25K) PRET PROFIT IMP  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) AMAR PROFIT  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) AMAR PROFIT IMP  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) AZUL PROFIT  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) AZUL PROFIT IMP  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) VERM PROFIT  
CHIP TONER LEXMARK CS 310 | 410 | 510 (3K) VERM PROFIT IMP  
CHIP TONER LEXMARK CS 310 | 410 | 510 (4K) PRET PROFIT  
CHIP TONER LEXMARK CS 310 | 410 | 510 (4K) PRET PROFIT IMP  
CHIP TONER LEXMARK CS | CX 310 | 410 | 510 (3K) AMAR PROFIT  
CHIP TONER LEXMARK CS | CX 310 | 410 | 510 (3K) AZUL PROFIT

CHIP TONER LEXMARK CS | CX 310 | 410 | 510 (3K) VERM PROFIT  
CHIP TONER LEXMARK CS | CX 310 | 410 | 510 (4K) PRET PROFIT  
CHIP TONER LEXMARK CX 410 | 510 (3K) AMAR PROFIT  
CHIP TONER LEXMARK CX 410 | 510 (3K) AMAR PROFIT IMP  
CHIP TONER LEXMARK CX 410 | 510 (3K) AZUL PROFIT  
CHIP TONER LEXMARK CX 410 | 510 (3K) AZUL PROFIT IMP  
CHIP TONER LEXMARK CX 410 | 510 (3K) VERM PROFIT  
CHIP TONER LEXMARK CX 410 | 510 (3K) VERM PROFIT IMP  
CHIP TONER LEXMARK CX 410 | 510 (4K) PRET PROFIT  
CHIP TONER LEXMARK CX 410 | 510 (4K) PRET PROFIT IMP  
CHIP TONER LEXMARK CX 417 (3,5K) AMAR PROFIT  
CHIP TONER LEXMARK CX 417 (3,5K) AZUL PROFIT  
CHIP TONER LEXMARK CX 417 (3,5K) VERM PROFIT  
CHIP TONER LEXMARK CX 417 (6K) PRET PROFIT  
CHIP TONER LEXMARK E120 (2K) PROFIT  
CHIP TONER LEXMARK E120 (2K) PROFIT IMP  
CHIP TONER LEXMARK E230 | 232 | 330 | 332 | 242 | 340 | 342 | X340 | X342 (6K) PROFIT  
CHIP TONER LEXMARK E230 | 232 | 330 | 332 | 242 | 340 | 342 | X340 | X342 (6K) PROFIT IMP  
CHIP TONER LEXMARK E250 | E350 | E352 (3,5K) PROFIT  
CHIP TONER LEXMARK E250 | E350 | E352 (3,5K) PROFIT IMP  
CHIP TONER LEXMARK E250 | E350 | E352 (9K) PROFIT  
CHIP TONER LEXMARK E250 | E350 | E352 (9K) PROFIT IMP  
CHIP TONER LEXMARK E260 | E360 | E460 (3,5K) PROFIT  
CHIP TONER LEXMARK E260 | E360 | E460 (3,5K) PROFIT IMP  
CHIP TONER LEXMARK E260 | E360 | E460 | E462 | X463 | X464 | X466 (15K) PROFIT  
CHIP TONER LEXMARK E260 | E360 | E460 | E462 | X463 | X464 | X466 (15K) PROFIT IMP  
CHIP TONER LEXMARK E360 | E460 | E462 (9K) PROFIT  
CHIP TONER LEXMARK E450 (11K) PROFIT  
CHIP TONER LEXMARK MICR ST9530 | ST9550 | T640 | T642 | T644 | X644 | X646 (15K) PROFIT  
CHIP TONER LEXMARK MICR ST9650 | T650 (15K) PROFIT  
CHIP TONER LEXMARK MS 310 | 410 | 510 | 610 (5K) PROFIT  
CHIP TONER LEXMARK MS 310 | 410 | 510 | 610 (5K) PROFIT IMP  
CHIP TONER LEXMARK MS 410 | 510 | 511 | 610 | 611 (10K) RESET PROFIT  
CHIP TONER LEXMARK MS 510 | 511 | 610 | 611 (20K) RESET PROFIT  
CHIP TONER LEXMARK MS 710 | 711 | 810 | 811 | 812 (25K) RESET PROFIT  
CHIP TONER LEXMARK MS | MX 317 | 417 | 517 (2,5K) PROFIT  
CHIP TONER LEXMARK MS | MX 317 | 417 | 517 (8,5K) PROFIT  
CHIP TONER LEXMARK MS | MX 321 (15K) PROFIT  
CHIP TONER LEXMARK MS | MX 410 | 510 | 511 | 610 | 611 (10K) PROFIT  
CHIP TONER LEXMARK MS | MX 410 | 510 | 511 | 610 | 611 (10K) PROFIT IMP  
CHIP TONER LEXMARK MS | MX 510 | 511 | 610 | 611 (20K) PROFIT  
CHIP TONER LEXMARK MS | MX 510 | 511 | 610 | 611 (20K) PROFIT  
CHIP TONER LEXMARK MS | MX 510 | 511 | 610 | 611 (20K) PROFIT IMP



CHIP TONER LEXMARK MS | MX 517 | 617 (20K) PROFIT  
CHIP TONER LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (25K) PROFIT  
CHIP TONER LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (25K) PROFIT IMP  
CHIP TONER LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (45K) PROFIT  
CHIP TONER LEXMARK MS | MX 710 | 711 | 810 | 811 | 812 (45K) PROFIT IMP  
CHIP TONER LEXMARK MS | MX 717 | 718 | 817 | 818 (25K) PROFIT  
CHIP TONER LEXMARK MX 310 | 410 | 511 | 611 (2,5K) PROFIT  
CHIP TONER LEXMARK MX 410 | 510 | 511 | 610 | 611 (10K) RESET PROFIT  
CHIP TONER LEXMARK MX 510 | 511 | 610 | 611 (20K) RESET PROFIT  
CHIP TONER LEXMARK MX 710 | 711 | 810 | 811 | 812 (25K) RESET PROFIT  
CHIP TONER LEXMARK MX 710 | 711 | 810 | 811 | 812 (45K) RESET PROFIT  
CHIP TONER LEXMARK T630 | T632 | T634 (21K) PROFIT  
CHIP TONER LEXMARK T630 | T632 | T634 (32K) PROFIT IMP  
CHIP TONER LEXMARK T640 | T642 | T644 (21K) PROFIT  
CHIP TONER LEXMARK T640 | T642 | T644 (21K) PROFIT IMP  
CHIP TONER LEXMARK T640 | T642 | T644 | X642 | X644 | X646 (32K) PROFIT  
CHIP TONER LEXMARK T640 | T642 | T644 | X642 | X644 | X646 (32K) PROFIT IMP  
CHIP TONER LEXMARK T650 | T652 | T654 | T656 | X650 | X652 | X654 | X656 (25K) PROFIT  
CHIP TONER LEXMARK T650 | T652 | T654 | T656 | X650 | X652 | X654 | X656 (25K) PROFIT IMP  
CHIP TONER LEXMARK T650 | T652 | T654 | T656 | X650 | X652 | X654 | X656 (36K) PROFIT  
CHIP TONER LEXMARK T650 | T652 | T654 | T656 | X650 | X652 | X654 | X656 (36K) PROFIT IMP  
CHIP TONER LEXMARK X203 | X204 (2,5K) PROFIT  
CHIP TONER LEXMARK X203 | X204 (2,5K) PROFIT IMP  
CHIP TONER LEXMARK X203 | X204 (6K) PROFIT  
CHIP TONER LEXMARK X203 | X204 (6K) PROFIT IMP  
CHIP TONER LEXMARK X264 | X363 | X364 (3,5K) PROFIT  
CHIP TONER LEXMARK X264 | X363 | X364 (9K) PROFIT  
CHIP TONER LEXMARK X264 | X363 | X364 (9K) PROFIT IMP  
CHIP TONER LEXMARK X340 | X342 (6K) PROFIT  
CHIP TONER LEXMARK X340 | X342 (6K) PROFIT IMP  
CHIP TONER LEXMARK XM3150 (16K) PROFIT  
CHIP TONER MINOLTA 3730 (3K) AMAR PROFIT  
CHIP TONER MINOLTA 3730 (3K) AZUL PROFIT  
CHIP TONER MINOLTA 3730 (3K) PRET PROFIT  
CHIP TONER MINOLTA 3730 (3K) VERM PROFIT  
CHIP TONER MINOLTA 4650 | 4690 | 4695 (8K) AMAR PROFIT  
CHIP TONER MINOLTA 4650 | 4690 | 4695 (8K) AZUL PROFIT  
CHIP TONER MINOLTA 4650 | 4690 | 4695 (8K) PRET PROFIT  
CHIP TONER MINOLTA 4650 | 4690 | 4695 (8K) VERM PROFIT  
CHIP TONER MINOLTA 4750 | 4790 | 4795 (6K) AMAR PROFIT  
CHIP TONER MINOLTA 4750 | 4790 | 4795 (6K) AZUL PROFIT  
CHIP TONER MINOLTA 4750 | 4790 | 4795 (6K) PRET PROFIT

CHIP TONER MINOLTA 4750 | 4790 | 4795 (6K) VERM PROFIT  
CHIP TONER MINOLTA 5550 | 5570 | 5650 | 5670 (12K) PRET PROFIT  
CHIP TONER MINOLTA 5650 (19K) PROFIT  
CHIP TONER MINOLTA 7450 (30K) AMAR PROFIT  
CHIP TONER MINOLTA 7450 (30K) AZUL PROFIT  
CHIP TONER MINOLTA 7450 (30K) VERM PROFIT  
CHIP TONER MINOLTA 7450 (50K) PRET PROFIT  
CHIP TONER MINOLTA 8650 (20K) AMAR PROFIT  
CHIP TONER MINOLTA 8650 (20K) AZUL PROFIT  
CHIP TONER MINOLTA 8650 (20K) VERM PROFIT  
CHIP TONER MINOLTA 8650 (26K) PRET PROFIT  
CHIP TONER MINOLTA BIZHUB C250 | C252 (45K) AMAR PROFIT  
CHIP TONER MINOLTA BIZHUB C250 | C252 (45K) AZUL PROFIT  
CHIP TONER MINOLTA BIZHUB C250 | C252 (45K) VERM PROFIT  
CHIP TONER MINOLTA BIZHUB C250 | C252 (70K) PRET PROFIT  
CHIP TONER MINOLTA BIZHUB C35 (6K) AMAR PROFIT  
CHIP TONER MINOLTA BIZHUB C35 (6K) AZUL PROFIT  
CHIP TONER MINOLTA BIZHUB C35 (6K) PRET PROFIT  
CHIP TONER MINOLTA BIZHUB C35 (6K) VERM PROFIT  
CHIP TONER OKIDATA B411 | MB431 | MB491 (12K) PROFIT  
CHIP TONER OKIDATA B411 | MB431 | MB491 (12K) PROFIT IMP  
CHIP TONER OKIDATA B4400 | B4600 (7K) PROFIT  
CHIP TONER OKIDATA B6300 (17K) PROFIT  
CHIP TONER OKIDATA B6500 (22K) PROFIT  
CHIP TONER OKIDATA C110 | C130 | MC160 (2,5K) AMAR PROFIT  
CHIP TONER OKIDATA C110 | C130 | MC160 (2,5K) AZUL PROFIT  
CHIP TONER OKIDATA C110 | C130 | MC160 (2,5K) PRET PROFIT  
CHIP TONER OKIDATA C110 | C130 | MC160 (2,5K) VERM PROFIT  
CHIP TONER OKIDATA C330 | C361 | C530 | MC561 (3,5K) PRET PROFIT  
CHIP TONER OKIDATA C330 | C361 | C530 | MC561 (3K) AMAR PROFIT  
CHIP TONER OKIDATA C330 | C361 | C530 | MC561 (3K) AZUL PROFIT  
CHIP TONER OKIDATA C330 | C361 | C530 | MC561 (3K) VERM PROFIT  
CHIP TONER OKIDATA C710 | C711 (11,5K) AMAR PROFIT  
CHIP TONER OKIDATA C710 | C711 (11,5K) AZUL PROFIT  
CHIP TONER OKIDATA C710 | C711 (11,5K) PRET PROFIT  
CHIP TONER OKIDATA C710 | C711 (11,5K) VERM PROFIT  
CHIP TONER OKIDATA C810 | C830 (8K) AMAR PROFIT  
CHIP TONER OKIDATA C810 | C830 (8K) AZUL PROFIT  
CHIP TONER OKIDATA C810 | C830 (8K) PRET PROFIT  
CHIP TONER OKIDATA C810 | C830 (8K) VERM PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) AMAR PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) AMAR PROFIT IMP

CHIP TONER OKIDATA C910 | C930 (17,5K) AZUL PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) AZUL PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) AZUL PROFIT IMP  
CHIP TONER OKIDATA C910 | C930 (17,5K) PRET PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) PRET PROFIT IMP  
CHIP TONER OKIDATA C910 | C930 (17,5K) VERM PROFIT  
CHIP TONER OKIDATA C910 | C930 (17,5K) VERM PROFIT IMP  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) AMAR PROFIT  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) AMAR PROFIT IMP  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) AZUL PROFIT  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) AZUL PROFIT IMP  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) PRET PROFIT  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) PRET PROFIT IMP  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) VERM PROFIT  
CHIP TONER OKIDATA C911 | C931 | C941 (38K) VERM PROFIT IMP  
CHIP TONER OKIDATA ES4132 | ES4192 | ES5112 | ES7115 (12K) PROFIT  
CHIP TONER OKIDATA ES4132 | ES4192 | ES5112 | ES7115 (12K) PROFIT IMP  
CHIP TONER OKIDATA MB260 | MB280 | MB290 (5,5K) PROFIT  
CHIP TONER OKIDATA MB410 | MB420 | MB430 | MB440 (3K) PROFIT  
CHIP TONER OKIDATA MB410 | MB420 | MB430 | MB440 (7K) PROFIT  
CHIP TONER OKIDATA MB460 | MB480 (12K) PROFIT  
CHIP TONER OKIDATA MB460 | MB480 (7K) PROFIT  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) AMAR PROFIT  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) AMAR PROFIT IMP  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) AZUL PROFIT  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) AZUL PROFIT IMP  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) VERM PROFIT  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (11,5K) VERM PROFIT IMP  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (15K) PRET PROFIT  
CHIP TONER OKIDATA MC760 | MC770 | MC780 (15K) PRET PROFIT IMP  
CHIP TONER OKIDATA UNIVERSAL C110 PRET | AZUL | AMAR | VERM PROFIT  
CHIP TONER OKIDATA UNIVERSAL C710 | C711 | C730 (11,5K) PRET | AZUL | AMAR | VERM PROFIT  
CHIP TONER OKIDATA UNIVERSAL C810 | C830 (8K) PRET | AZUL | AMAR | VERM PROFIT  
CHIP TONER RICOH AC205 (5K) PROFIT  
CHIP TONER RICOH C2030 | C2050 | C2530 | C2550 | C2051 (10K) PRET PROFIT  
CHIP TONER RICOH C2030 | C2050 | C2530 | C2550 | C2051 (9,5K) AMAR PROFIT  
CHIP TONER RICOH C2030 | C2050 | C2530 | C2550 | C2051 (9,5K) AZUL PROFIT  
CHIP TONER RICOH C2030 | C2050 | C2530 | C2550 | C2051 (9,5K) VERM PROFIT  
CHIP TONER RICOH C250 | C252 (1,6K) AMAR PROFIT  
CHIP TONER RICOH C250 | C252 (1,6K) AZUL PROFIT  
CHIP TONER RICOH C250 | C252 (1,6K) VERM PROFIT  
CHIP TONER RICOH C250 | C252 (2K) PRET PROFIT  
CHIP TONER RICOH C3002 | C3502 (18K) AMAR PROFIT

CHIP TONER RICOH C3002 | C3502 (18K) AZUL PROFIT  
CHIP TONER RICOH C3002 | C3502 (18K) VERM PROFIT  
CHIP TONER RICOH C3002 | C3502 (28K) PRET PROFIT  
CHIP TONER RICOH C3003 | C3503 | C3504 (18K) AMAR PROFIT  
CHIP TONER RICOH C3003 | C3503 | C3504 (18K) AZUL PROFIT  
CHIP TONER RICOH C3003 | C3503 | C3504 (18K) VERM PROFIT  
CHIP TONER RICOH C3003 | C3503 | C3504 (29,5K) PRET PROFIT  
CHIP TONER RICOH MP401 (12K) PROFIT  
CHIP TONER RICOH MP401 | 4520DN (10,4K) PROFIT  
CHIP TONER RICOH MP401 | 4520DN (10,4K) PROFIT IMP  
CHIP TONER RICOH MPC2003 | MPC2503 (15K) AMAR PROFIT  
CHIP TONER RICOH MPC2003 | MPC2503 (15K) AZUL PROFIT  
CHIP TONER RICOH MPC2003 | MPC2503 (15K) PRET PROFIT  
CHIP TONER RICOH MPC2003 | MPC2503 (15K) VERM PROFIT  
CHIP TONER RICOH MPC300 | MPC400 (10K) AMAR PROFIT  
CHIP TONER RICOH MPC300 | MPC400 (10K) AZUL PROFIT  
CHIP TONER RICOH MPC300 | MPC400 (10K) PRET PROFIT  
CHIP TONER RICOH MPC300 | MPC400 (10K) VERM PROFIT  
CHIP TONER RICOH MPC305 (12K) PRET PROFIT  
CHIP TONER RICOH MPC305 (4K) AMAR PROFIT  
CHIP TONER RICOH MPC305 (4K) AZUL PROFIT  
CHIP TONER RICOH MPC305 (4K) VERM PROFIT  
CHIP TONER RICOH MPC406 (17K) PRET PROFIT  
CHIP TONER RICOH MPC406 (6K) AMAR PROFIT  
CHIP TONER RICOH MPC406 (6K) AZUL PROFIT  
CHIP TONER RICOH MPC406 (6K) VERM PROFIT  
CHIP TONER RICOH Q6472A | 3505 | 3600 | 3800 (4K) AMAR PROFIT  
CHIP TONER RICOH Q6472A | 3505 | 3600 | 3800 (4K) AZUL PROFIT  
CHIP TONER RICOH Q6472A | 3505 | 3600 | 3800 (4K) PRET PROFIT  
CHIP TONER RICOH Q6472A | 3505 | 3600 | 3800 (4K) VERM PROFIT  
CHIP TONER RICOH SP231 | SP232 (6K) AMAR PROFIT  
CHIP TONER RICOH SP231 | SP232 (6K) AZUL PROFIT  
CHIP TONER RICOH SP231 | SP232 (6K) PRET PROFIT  
CHIP TONER RICOH SP231 | SP232 (6K) VERM PROFIT  
CHIP TONER RICOH SP310 | SP311 (6,4K) PROFIT IMP  
CHIP TONER RICOH SP3200 (8K) PROFIT  
CHIP TONER RICOH SP3200 (8K) PROFIT IMP  
CHIP TONER RICOH SP3300 (5K) PROFIT  
CHIP TONER RICOH SP3400 | SP3410 | SP3510 (6K) PROFIT  
CHIP TONER RICOH SP3400 | SP3410 | SP3510 (6K) PROFIT IMP  
CHIP TONER RICOH SP3710 (7K) PROFIT  
CHIP TONER RICOH SP3710 (7K) PROFIT IMP

CHIP TONER RICOH SP377 (6,4K) PROFIT  
CHIP TONER RICOH SP377 (6,4K) PROFIT IMP  
CHIP TONER RICOH SP430 (15K) AMAR PROFIT  
CHIP TONER RICOH SP430 (15K) AZUL PROFIT  
CHIP TONER RICOH SP430 (15K) PRET PROFIT  
CHIP TONER RICOH SP430 (15K) VERM PROFIT  
CHIP TONER RICOH SP4500 | SP4510 (12K) PROFIT  
CHIP TONER RICOH SP4500 | SP4510 (12K) PROFIT IMP  
CHIP TONER RICOH SP5200 | 5210 (25K) PROFIT  
CHIP TONER RICOH SP5200 | 5210 (25K) PROFIT IMP  
CHIP TONER RICOH SP5300 | 5310 (25K) PROFIT  
CHIP TONER SAMSUNG CLP350 (2K) AMAR PROFIT  
CHIP TONER SAMSUNG CLP350 (2K) AZUL PROFIT  
CHIP TONER SAMSUNG CLP350 (2K) PRET PROFIT  
CHIP TONER SAMSUNG CLP350 (2K) VERM PROFIT  
CHIP TONER SAMSUNG CLT404S | SLC430 | C480 (1K) AMAR PROFIT  
CHIP TONER SAMSUNG CLT404S | SLC430 | C480 (1K) AZUL PROFIT  
CHIP TONER SAMSUNG CLT404S | SLC430 | C480 (1K) PRET PROFIT  
CHIP TONER SAMSUNG CLT404S | SLC430 | C480 (1K) VERM PROFIT  
CHIP TONER SAMSUNG CLT406 | CLX3305 | CLP365 (1,5K) PRET PROFIT  
CHIP TONER SAMSUNG CLT406 | CLX3305 | CLP365 (1K) AMAR PROFIT  
CHIP TONER SAMSUNG CLT406 | CLX3305 | CLP365 (1K) AZUL PROFIT  
CHIP TONER SAMSUNG CLT406 | CLX3305 | CLP365 (1K) VERM PROFIT  
CHIP TONER SAMSUNG CLT407 | CLP320 | CLP325 | CLX3185 (1,5K) PRET PROFIT  
CHIP TONER SAMSUNG CLT407 | CLP320 | CLP325 | CLX3185 (1K) AMAR PROFIT  
CHIP TONER SAMSUNG CLT407 | CLP320 | CLP325 | CLX3185 (1K) AZUL PROFIT  
CHIP TONER SAMSUNG CLT407 | CLP320 | CLP325 | CLX3185 (1K) VERM PROFIT  
CHIP TONER SAMSUNG CLT409 | CLP310 | CLP315 | CLX3175 (1,5K) PRET PROFIT  
CHIP TONER SAMSUNG CLT409 | CLP310 | CLP315 | CLX3175 (1K) AMAR PROFIT  
CHIP TONER SAMSUNG CLT409 | CLP310 | CLP315 | CLX3175 (1K) AZUL PROFIT  
CHIP TONER SAMSUNG CLT409 | CLP310 | CLP315 | CLX3175 (1K) VERM PROFIT  
CHIP TONER SAMSUNG CLT506L | CLP680 | CLX6260FD (3,5K) AMAR PROFIT IMP  
CHIP TONER SAMSUNG CLT506L | CLP680 | CLX6260FD (3,5K) AZUL PROFIT IMP  
CHIP TONER SAMSUNG CLT506L | CLP680 | CLX6260FD (3,5K) VERM PROFIT IMP  
CHIP TONER SAMSUNG CLT506L | CLP680 | CLX6260FD (6K) PRET PROFIT IMP  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) AMAR PROFIT  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) AMAR PROFIT IMP  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) AZUL PROFIT  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) AZUL PROFIT IMP  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) PRET PROFIT  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) PRET PROFIT IMP  
CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) VERM PROFIT

CHIP TONER SAMSUNG CLT609 | CLP770 | CLP775ND (7K) VERM PROFIT IMP  
CHIP TONER SAMSUNG ML-D3470B | ML3470 | ML3471 (10K) PROFIT  
CHIP TONER SAMSUNG ML-D4550A | ML4550 | ML4551 (20K) PROFIT  
CHIP TONER SAMSUNG ML2250 | ML2251 | ML2252 (5K) PROFIT  
CHIP TONER SAMSUNG ML2850 | ML2851 (5K) PROFIT  
CHIP TONER SAMSUNG ML2850 | ML2851 (5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D101S | ML2160 | ML2165 | ML2166 | SCX3400 (1,5K) PROFIT  
CHIP TONER SAMSUNG MLT-D103L | ML2955 | SCX4729 (2,5K) PROFIT  
CHIP TONER SAMSUNG MLT-D103L | ML2955 | SCX4729 (2,5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D104S | ML1660 | ML1665 | ML1666 | ML1865 | SCX3200 (1,5K) PROFIT  
CHIP TONER SAMSUNG MLT-D104S | ML1660 | ML1665 | ML1666 | ML1865 | SCX3200 (1,5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D105L | ML1915 | ML2525 | ML2580 | SCX4600 ( 2,5K ) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D105L | ML1915 | ML2525 | ML2580 | SCX4600 (2,5K) PROFIT  
CHIP TONER SAMSUNG MLT-D108S | ML1640 | ML1641 | ML2240 | ML2241 (1,5K) PROFIT  
CHIP TONER SAMSUNG MLT-D109S | SCX4300 (2K) PROFIT  
CHIP TONER SAMSUNG MLT-D111L | M2020 | M2070 (1,8K) FIRM ATUALIZADO PROFIT  
CHIP TONER SAMSUNG MLT-D111L | M2020 | M2070 (1,8K) FIRM ATUALIZADO PROFIT IMP  
CHIP TONER SAMSUNG MLT-D111L | M2020 | M2070 (1,8K) PROFIT  
CHIP TONER SAMSUNG MLT-D111L | M2020 | M2070 (1,8K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D111S | M2020 | M2070 (1K) PROFIT  
CHIP TONER SAMSUNG MLT-D116L | M2825 | M2835 | M2875 | M2885 (3K) PROFIT  
CHIP TONER SAMSUNG MLT-D116L | M2825 | M2835 | M2875 | M2885 (3K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D201L | M4030ND | M4080FX (20K) PROFIT  
CHIP TONER SAMSUNG MLT-D201L | M4030ND | M4080FX (20K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D201S | M4030ND | M4080FX (10K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D203E | M3820 | M3870 | M4020 | M4070 (10K) PROFIT  
CHIP TONER SAMSUNG MLT-D203L | M3820 | M3870 | M4020 | M4070 (5K) PROFIT  
CHIP TONER SAMSUNG MLT-D203U | M3820 | M3870 | M4020 | M4070 (15K) PROFIT  
CHIP TONER SAMSUNG MLT-D203U | M3820 | M3870 | M4020 | M4070 (15K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D203U | M3820 | M3870 | M4020 | M4070 (15K) PROFIT NEW  
CHIP TONER SAMSUNG MLT-D204L | M3325 | M3375 | M3825 | M3875 (5K) PROFIT  
CHIP TONER SAMSUNG MLT-D204L | M3325 | M3375 | M3825 | M3875 (5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D204U | M3325 | M3375 | M3825 | M3875 (15K) PROFIT  
CHIP TONER SAMSUNG MLT-D205E | ML3310 | ML3710 | SCX4833 | SCX5637 (10K) PROFIT  
CHIP TONER SAMSUNG MLT-D205E | ML3310 | ML3710 | SCX4833 | SCX5637 (10K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D205L | ML3310 | ML3710 | SCX4833 | SCX5637 (5K) PROFIT  
CHIP TONER SAMSUNG MLT-D205L | ML3310 | ML3710 | SCX4833 | SCX5637 (5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D208L | SCX5635 | SCX5835 (10K) PROFIT  
CHIP TONER SAMSUNG MLT-D208L | SCX5635 | SCX5835 (10K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D209L | ML2855 | SCX4824 | SCX4826 | SCX4828 (5K) PROFIT  
CHIP TONER SAMSUNG MLT-D209L | ML2855 | SCX4824 | SCX4826 | SCX4828 (5K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D303E | M4580 (40K) PROFIT  
CHIP TONER SAMSUNG MLT-D303E | M4580 (40K) PROFIT IMP

CHIP TONER SAMSUNG MLT-D305L | ML3750 (15K) PROFIT  
CHIP TONER SAMSUNG MLT-D305L | ML3750 (15K) PROFIT IMP  
CHIP TONER SAMSUNG MLT-D307E | ML4510 | ML4512 | ML5012 | ML5015 (20K) PROFIT  
CHIP TONER SAMSUNG MLT-D307U | ML4510 | ML4512 | ML5012 | ML5015 (30K) PROFIT  
CHIP TONER SAMSUNG MLT-D309L | ML5510 | ML6510 (30K) PROFIT  
CHIP TONER SAMSUNG SCX-D6555 | SCX6545 (25K) PROFIT  
CHIP TONER SAMSUNG SCX-D6555 | SCX6545 (25K) PROFIT IMP  
CHIP TONER SAMSUNG SCX4200 | MULTIREGIONAL | DOM (3K) PROFIT  
CHIP TONER SAMSUNG SCX4200 | MULTIREGIONAL | DOM (3K) PROFIT IMP  
CHIP TONER SAMSUNG SCX4520 | SCX4720 (5K) PROFIT  
CHIP TONER SAMSUNG SCX4725 (3K) PROFIT  
CHIP TONER SAMSUNG SCX4725 (3K) PROFIT IMP  
CHIP TONER SAMSUNG SCX6120 | SCX6220 | SCX6320 (8K) PROFIT  
CHIP TONER SHARP 5020 | AR5016 | AR5220 PROFIT  
CHIP TONER SHARP AL2041 | 2021 | 2031 | 2051 KATUN  
CHIP TONER SHARP AL235 | AL310 | 235 | 237 | 257 | 277 | M208 | M317 | N275 | 5127 (25K) PROFIT  
CHIP TONER SHARP AR016 | AR5016 | AR5020 | AR5220 PROFIT  
CHIP TONER SHARP AR450 | M280N | M350U (27K) PROFIT  
CHIP TONER SHARP AR455 | M355N | M45U | M455N | M455U (35K) PROFIT  
CHIP TONER XEROX 106R03943 | B600 | B605 | B610 | B615 (25,9K) PROFIT  
CHIP TONER XEROX 3020 | 3025 (1,5K) PROFIT  
CHIP TONER XEROX 3020 | 3025 (1,5K) PROFIT IMP  
CHIP TONER XEROX 3119 (3K) PROFIT  
CHIP TONER XEROX 4600 | 4620 (30K) PROFIT  
CHIP TONER XEROX 6000 | 6010 | 6015 (1K) AMAR PROFIT  
CHIP TONER XEROX 6000 | 6010 | 6015 (1K) AZUL PROFIT  
CHIP TONER XEROX 6000 | 6010 | 6015 (1K) VERM PROFIT  
CHIP TONER XEROX 6000 | 6010 | 6015 (2K) PRET PROFIT  
CHIP TONER XEROX B405 (25,9K) PROFIT  
CHIP TONER XEROX B600 | B605 | B610 | B615 (25,9K) PROFIT IMP  
CHIP TONER XEROX FAX CENTRE 3100 (4K) PROFIT  
CHIP TONER XEROX PHASER 3010 | 3040 | 3045 (2K) PROFIT  
CHIP TONER XEROX PHASER 3052 | 3215 | 3225 | 3260 (3K) PROFIT  
CHIP TONER XEROX PHASER 3052 | 3215 | 3225 | 3260 (3K) PROFIT IMP  
CHIP TONER XEROX PHASER 3140 | 3155 | 3160 (2,5K) PROFIT  
CHIP TONER XEROX PHASER 3200 (3K) PROFIT  
CHIP TONER XEROX PHASER 3210 | 3220 (4K) PROFIT  
CHIP TONER XEROX PHASER 3250 (5K) PROFIT  
CHIP TONER XEROX PHASER 3300 (8K) PROFIT  
CHIP TONER XEROX PHASER 3315 | 3320 | 3325 (11K) PROFIT  
CHIP TONER XEROX PHASER 3315 | 3320 | 3325 (11K) PROFIT  
CHIP TONER XEROX PHASER 3315 | 3320 | 3325 (5K) PROFIT

CHIP TONER XEROX PHASER 3315 | 3320 | 3325 (5K) PROFIT  
CHIP TONER XEROX PHASER 3428 (8K) PROFIT  
CHIP TONER XEROX PHASER 3435 (10K) PROFIT  
CHIP TONER XEROX PHASER 3500 (12K) PROFIT  
CHIP TONER XEROX PHASER 3550 (11K) PROFIT  
CHIP TONER XEROX PHASER 3600 (14K) PROFIT  
CHIP TONER XEROX PHASER 3610 | 3615 (14,1K) PROFIT  
CHIP TONER XEROX PHASER 3610 | 3615 (14,1K) PROFIT IMP  
CHIP TONER XEROX PHASER 3635 (10K) PROFIT  
CHIP TONER XEROX PHASER 3635 (5K) PROFIT  
CHIP TONER XEROX PHASER 3655 (25,9K) PROFIT  
CHIP TONER XEROX PHASER 3655 (25,9K) PROFIT IMP  
CHIP TONER XEROX PHASER 4118 (8K) PROFIT  
CHIP TONER XEROX PHASER 4510 (19K) PROFIT  
CHIP TONER XEROX PHASER 6180 (6K) AMAR PROFIT  
CHIP TONER XEROX PHASER 6180 (6K) AZUL PROFIT  
CHIP TONER XEROX PHASER 6180 (6K) VERM PROFIT  
CHIP TONER XEROX PHASER 6180 (8K) PRET PROFIT  
CHIP TONER XEROX PHASER 6280 (5,9K) AMAR PROFIT  
CHIP TONER XEROX PHASER 6280 (5,9K) AZUL PROFIT  
CHIP TONER XEROX PHASER 6280 (5,9K) VERM PROFIT  
CHIP TONER XEROX PHASER 6280 (7K) PRET PROFIT  
CHIP TONER XEROX PHASER 6500 | 6505 (2,5K) AMAR PROFIT  
CHIP TONER XEROX PHASER 6500 | 6505 (2,5K) AZUL PROFIT  
CHIP TONER XEROX PHASER 6500 | 6505 (2,5K) VERM PROFIT  
CHIP TONER XEROX PHASER 6500 | 6505 (3K) PRET PROFIT  
CHIP TONER XEROX PHASER 7500 (17,8K) AMAR PROFIT  
CHIP TONER XEROX PHASER 7500 (17,8K) AZUL PROFIT  
CHIP TONER XEROX PHASER 7500 (17,8K) VERM PROFIT  
CHIP TONER XEROX PHASER 7500 (19,8K) PRET PROFIT  
CHIP TONER XEROX PHASER 7800 (12K) AMAR PROFIT  
CHIP TONER XEROX PHASER 7800 (12K) AZUL PROFIT  
CHIP TONER XEROX PHASER 7800 (12K) VERM PROFIT  
CHIP TONER XEROX PHASER 7800 (18K) PRET PROFIT  
CHIP TONER XEROX PHASER PE220 (3K) PROFIT  
CHIPLESS P/ EPSON WORKFORCE 5710 | 5790 | 5799 | 5210 PROFIT